
DOVGV.2

Cover for flush floor trunking



For hinged cover KDVKK2 and KDVIRK2.

Reference	↕ mm	↔ mm	→‖← mm	⇄ mm	kg/stk	⬡	Unit
DOVGV250.3.2		250	3	800	3,313	1	STK

Replace the clamps of the hinged cover by the enclosed clamps of the DOVG. Replace the cover where you want to mount the flush mounting unit with a cover for the relevant flush mounting unit. Place the flush mounting unit in the opening provided. Fasten the flush mounting unit by tightening the clamps.